



Spare Parts – BR-22

UW101/102	Handle Set, Left & Right
UW103/112	Torch Head & Cable Assembly
UW104	Collet Nut
UW105	Neoprene Compression Washer
UW107	Flash Arrestor with Screen
UW109	Lever
UW110	Valve Stem (includes O-Ring)
UW111	Coupler Assembly
UW113	Control Valve Body
UW114	Valve Stem Spring
UW115	Control Valve Nut
UW116	Valve Stem O-Ring
UW117	Neoprene Valve Stem Washer
UW118	Valve Nut Gasket
UW119/120	Brass Screw & Locknut
UW121/122	Nylon Screws & Nuts (Four Each)
UW123	Collet Washer
UW7A	Control Valve Assembly